# Teladoc Health Mini™ Backpack



#### **Installation Guide**

# **Mini Backpack Installation**

The Mini has an optional Backpack Accessory (20-20335) available that can be added to the cart to provide enclosed storage.

#### What's needed

• Philips head screwdriver

### **Installing the Backpack**

- 1. Carefully slide the backpack onto the cart and line up the holes on each side of the backpack.
- Attach the backpack using six M4x6mm (included, x6, 3 on each side) screws and a Philips head screwdriver.

